

Hoist Drum Rotation Indicators


The **indicators** are designed to give the operators an additional feeling and visual indication of **hoist drum** movement when the **hoist drums** can not be viewed by the operators.

General Description

The system consists of three different components for each **hoist**: a **transmitter**, a **driver** and an **indicator**. The system is bi-directional and extremely precise. The system can be installed on any or all of the **hoists** on a crane.



The transmitter is directly driven by the hoist drum.



The indicator is located on the seat arm directly in front of the boom hoist joystick.