



Seatrax Optional Boom Walkways *with Boom Maintenance and Work Platform Packages*

The Seatrax boom maintenance and work platform package includes a walkway down the side of the **boom** and is accessible from the engine deck side of the crane. Also included is a u-shaped maintenance platform at the boom tip from which servicing of all of the **boom** tip machinery, such as **sheaves, main block, auxiliary hook, boom lights** and **SLI sensors**, can take place. The walkway and platforms include bar grating, toe plates, mid rails and handrails.



- 1** The boom maintenance and work platform package extends along the entire length of the boom.
- 2** Access is accomplished from the front door of the machinery house and machinery house foredeck via stairs or ladder.
- 3** An u-shaped maintenance platform is located around the boom tip.





4 Sheaves, main block, auxiliary hook, boom lights and SLI are easily serviced from the boom tip portion of the platform.

5 Hoists are easily accessed from the widened area of the platform at the boom heel.

6 Lighting packages are more accessible with the walkway package.